




MULTI-SURFACE POLISH

CLEANING INSTRUCTIONS




Uses:

To polish and protect plastic laminate, painted metal, rubber hoses and more surfaces.


Frequency: Weekly, or as needed

For best results, clean surface prior to polishing with OTIS surface cleaner.



To Polish:

1. Open lid, and remove LUXSS wipe from the canister and then reseal lid
2. Wipe surface with LUXSS wipe applying even pressure
3. Repeat as necessary



MSDS available at www.mycaf.com

Scan for videos, MSDS, training and more.



www.mycaf.com/luxss.php



For questions or product information, please contact CAF (425) 433-8277 or visit www.mycaf.com