

APPLICATION INSTRUCTIONS

EFFECTIVE ON

- Stainless steel
- Painted metal
- Aluminum
- Mechanical finishes
- Plastic surfaces
- Rubber
- Other surfaces

FREQUENCY


As needed. For best results, use once a week to keep equipment protected from UV rays and additional dust.

TASK DURATION

1-4 minutes per task when used weekly.

TIPS

- To avoid excessive residue, spray PROTERO onto a microfiber cloth.
- Product is very efficient, use in moderation.



PREP

Be sure to have latex gloves, hand towels and safety vest when polishing areas around the fueling dispensers.

TO POLISH

1. Apply ready to use spray directly to a cleaning towel or a dry metal surface.
2. Wipe surface to polish and shine.
3. Repeat as necessary.

Note: Do not spray and polish on glass as it will leave streaking on surface.



HAVE QUESTIONS? NEED TRAINING?
WE'RE HERE TO HELP!



Visit www.mycaf.com for additional product information, SDS, training materials, product videos and more.

